

GCA2 - For below device vertical 7/16 connection protection

1. Before connecting the feeder to the device ease a GCA2 over the connector nut with the narrow end of the GCA2 pointing upwards towards the device.
2. Keep the GCA2 clear as you make the connection to the device at the correct torque.
3. Ease the GCA2 fully over the connector nut and socket so that it is pushed up tight to the underside of the device. There should be no gap between the socket back plate/ and the top of the GCA2 device.



Install: Note correct connector and socket body fully covered with no top gap between device and GCA2.

Note: For Above device/connection protection use GCA2 + Bung (14 or 16mm). Refer to GCA2 + Bung install sheet for correct installation method (supplied with bungs).