

1. Install on Jumper before Connection

Stretch the wider bottom end of the GCA5 down past the male 4.3-10 nut before connection and tightening of the connector to correct torque.

**2. Squeeze the cone end to install the GCA5**

The GCA5 uses a tight tolerance so needs a simple squeezing motion to enable it to ride over the torqued connector nut, recover its shape, and locate on the female connector under the antenna or MHA.

**3. Finished Location**

Ensure the GCA5 has recovered its original shape and the cone/ angled end is pushed up flush and tight against the connector mounting plate / component.

